Warranty

All retail parts carry a 90-day warranty from the date of purchase. This warranty covers defects in materials or workmanship, and does not include (i) normal wear and tear, environmental conditions, improper installation; (ii) road hazards, misuse, abuse, neglect, accidents, collision, fire, theft, freezing, vandalism, riot, explosion, or objects striking the vehicle; (iii) misusing the vehicle, such as driving over curbs, overloading, racing, or using the vehicle as a stationary power source; (iv) altering, disassembling or modifying the parts; (v) defects caused or induced by failures, breakdowns, or damage by other parts, components or the vehicle; (vi) subjecting the parts to excessive moisture or water or any motor vehicle fluids (e.g.: oil, anti-freeze, battery acid, brake fluid, etc.); (vii) acts of God, natural disasters and other similar causes beyond the reasonable control of MRT; (viii) application of chemicals that affect the parts; or (ix) damaged caused by automated car washes. This Limited Warranty does not cover surface deterioration of paint, trim, and appearance items that result from use and/or exposure to the elements, such as stone chips, scratches, bird droppings, lightning, hail, windstorm, dings, dents, earthquake, road salt, tree sap, water or flood.

MRT SHALL NOT BE LIABLE TO REIMBURSE CUSTOMER/DEALER FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE INSTALLATION OR USE OF ANY PRODUCT SOLD THROUGH THIS CATALOG OR ARISING OUT OF ANY BREACH OF WARRANTY, EXCEPT AS MAY BE STATED IN THIS CATALOG, MRT DISCLAIMS ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL MRT'S LIABILITY EXCEED THE PRICE PAID BY CUSTOMER/DEALER FOR PRODUCTS SOLD REGARDLESS IF MRT HAS BEEN ADVISED IN ADVANCE OF ANY POTENTIAL PROBLEM OR IF A CLAIM IS BASED ON CONTRACT. TORT, STRICT LIABILITY. PRODUCT LIABILITY OR OTHERWISE. SOME STATES DONOTALLOW THE EXCLUSION OR LIMITATION OF IMPLIED WARRANTIES OR THEIR DURATION, OR LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSIONS OR LIMITATIONS MAY NOT APPLY.

MRT appreciates your business. Please feel free to contact us at any point with questions or concerns at 734-455-5807 or Sales@MRT-Direct.com



Louver Installation

- 1. Clean Window with Isopropyl Alcohol. Place a 5" piece of masking tape on center top edge of glass. Mark center of glass on tape with a pen. (Figure 2)
- 2. Cut Out Template. Center and tape it on upper part of glass.
- 3. Apply adhesion promoter in upper pad areas. Close the packet to slow evaporation.
- 4. Check location of hinge pads: use masking tape to attach to glass and position louver on top to ensure louver hinge lines up with hinge pad studs.
- 5. Peel the tape from the hinge pads and mount in place. (Note: Studs on hinge pad are not centered. Install with studs offset towards trunk lid. See Figure 4.) Press firmly and rub with the back end of a screw driver.
- 6. Prep louver as shown on Page 2. Install prop rods.
- 7. Attach the louver and hinges to the hinge pads: Put washer plates over hinges and apply the nuts loosely. Then align the louver so it is centered at the top of the glass. Tighten the hinge nuts with 11/32" wrench.
- 8. Secure the latch pads on the lower latch clips. Lower the louver to check pad locations while pressing on the lower center to hold the feet down. Then use masking tape to frame the area, apply promoter to the area, and stick in place.
- 9. Allow 24 hours for tape to cure before exposing to direct sun or freezing conditions.



