




P.O. Box 1719
Corona, CA 92878
Support: 877-512-8111
www.aFefilters.com

Intake Kit Installation Instructions: 2004-2005 Ford F-150 5.4L V8

Kit Part #	54-10512	Tools Required	Part List:	2- 8-32 x 5/8" screws
	51-10512 Pro Dry S	8mm socket 5/16" nut driver 10mm socket Flathead screwdriver Ratchet and extension T-20 Torx Bit	1- Air filter P/N (24-90008 or Pro Dry S P/N 21-90008) 1- Air filter Housing 1- Intake tube rotomolded 1- Intake tube support mount 1- Housing support tab 1- MAF sensor gasket 4- M6 Button head screws 5- M6 x 12 hex head screws 9- M6 washers	2- M6 Wavy washers 4- Clamps #064 2- Nylon spacers 1/8" 1- Coupler (4" x 3") 1- Coupler (3.5" x 4.0") 1- Hose, Vent (5/16" x 17") 35"- Trim seal 3/4" bulb 1- M6 nut
Make:	Ford			
Model:	F-150			
Engine:	V-8 5.4L			
Year:	2004-2006			
Note: Please confirm Parts List and read all instructions steps before proceeding with actual installation.				



Note: Filter Cleaning and Re-oiling: When cleaning your aFe filter, be sure to use only aFe's "Restore Kit" (aFe P/N: 90-50001 blue oil aerosol, or aFe P/N: 90-50501 blue squeeze bottle oil or aFe P/N: 90-50000 gold oil aerosol, or aFe P/N: 90-50500 gold squeeze oil). On Filter Replacement: Magnum FLOW PN: 24-90008 (black w/ blue media). Pro Dry S P/N 21-90008 (black w/ white media). Pro Dry S cleaning: see cleaning instruction sheet 06-00074