



INSTALLATION INSTRUCTIONS

MAKE: BMW
MODEL: 135i (tt)
YEAR: 2008-2009
ENGINE: L6-3.0L



3" Cat-Back

- 49-36302 (304 SS)
- 49-46302 (409 SS)
- 49-46303 (409 SS)



Step 1: (Read Instructions prior to installation) Disconnect vacuum hose at left side exhaust tip valve. Cap with supplied plug. Remove your stock exhaust from your vehicle. Save and take caution not to damage the factory isolation mounts, mounting bolts and springs as they will be reused. **It is recommended to not fully tighten the clamps until the entire system has been installed.**

Step 2: Install tail-pipe assembly. Re-use factory flange bolts, springs and isolation mounts.

Step 3: Adjust for alignment and tighten all connections. Your installation is now complete. It is recommended to re-tighten all exhaust components after the first 50-100 miles.

NOTE:

- aFe recommends that the tailpipe be at least 1/2"-1" away from any body panels to avoid heat related body damage. **Tighten and secure.**

Caution: Allow time for your vehicle to cool down prior to installation. When working on or under your vehicle proceed with caution. Exhaust systems reach high temperatures and may cause serious burns. Wear protective safety equipment; eye goggles and gloves to ensure a safe installation. **aFe recommends professional installation on our products.**