



# **Installation Instructions: TR-0020**

## **08-10 Ford Super Duty**

### **Rigid Dually XL Adapter Brackets**

The TR-0020 Adapter Brackets for 08-10 Ford Super Duty Trucks allows you to install a set of Rigid Industries Dually XL lights into onto the factory fog light brackets. Some modification to the factory bracket is required.



1. Remove the factory fog light brackets from the inside of the bumper by first unplugging the fog light from the factory wiring. Remove the 3 bolts holding each bracket onto the inside of the bumper and pull the assembly out.
2. Remove the factory fog light from the plastic bracket by releasing the plastic pins on the sides, and removing the adjustment screw with spring on the bottom. You will not re-use these items.
3. Cut off the two plastic tabs on the bracket flush with the bracket face. See photo 1.
4. Using a 1/4" drill bit, drill out the top two existing holes in the factory bracket.
5. Install the KD Fabworks bracket with the supplied 6mm bolts, washers, and nylocs.
6. Install the Rigid Dually XL onto the KD Fabworks bracket using the hardware included with the light
7. Plug the KD Fabworks adapter harness into the back of the Rigid Light.
8. Reinstall the whole assembly back into the vehicle and secure with the factory bolts removed in step 1.



Photo 1



Photo 2



*Thank you for purchasing a product from KD Fabworks!*

**KD Fabworks**  
**www.KDfabworks.com**  
**888.535.1580**



© KD Fabworks 2015