



Installation Instructions: TR-1005 2010-2016 Dodge RAM 2500/3500 40" Curved LED Light Bar Brackets

Installation of these brackets required removal of the factory tow hooks from the truck using an 18mm socket and wrench. Once removed, you will install the KD Fabworks brackets using the factory hardware on the outer bolt locations. The brackets have slotted holes to allow for some adjustability depending on bar width, and alignment within the bumper opening.



Thank you for purchasing a product from KD Fabworks!

***KD Fabworks, LLC
www.KDfabworks.com
888.535.1580***



© KD Fabworks, LLC 2016