

INSTALLATION INSTRUCTIONS

PART No.

FB21066

Jeep® JK Wrangler Hood Light Bar Mount









REQUIRED TOOLS

T-50 Torx 5mm Allen wrench

KIT CONTAINS Bracket (left and right) Spacer 4 Stainless button head bolts 4

1) REMOVE FACTORY BOLTS

Using a T-50 torx, remove the factory bolts holding the hood hinges in place.



2) INSTALL BRACKETS

Install the brackets by placing two (2) spacers on each hood hinge. Place the bracket on top of the

spacers ensuring the mounting hole for the light faces inward towards the middle of the Jeep. Using the supplied bolts, loosely secure the bracket in place. The bracket should be tight enough to keep it from falling over, but loose enough to allow adjustments for the light.



2106600



INSTALLATION INSTRUCTIONS

PART No.

FB21066

Jeep® JK Wrangler Hood Light Bar Mount



Install the second bracket following the same procedure.

3) INSTALL LIGHT BAR

Follow your light manufacturer's instructions to install the light using the new brackets.



4) TIGHTEN ALL HARDWARESecure the brackets using a 5mm allen wrench.

5) GO LIGHT UP THE TRAILS AND ENJOY YOUR NEW FISHBONE OFFROAD HOOD LIGHT BAR MOUNT!