


INSTALLATION INSTRUCTIONS
Wakeboard Speaker Mount:
for Polaris Ranger[®] (Full and Mid size)



Wedge Clamp Assembly:

- Set Screw
- Clamp Top
- Clamp Bottom

(Ranger[®] XP 900 will not require Brackets)

8x  M8-1.25 x 16mm Lg. FHCS

8x  M8-1.25 Nylock Nut 8x  M8 Flat Washer

Read instructions and view illustrations before beginning.

Need help with your installation?

 sales@superatv.com  www.superatv.com

 1-812-574-7777  8:00am - 9:00pm EST M-Th
 8:00am - 7:00pm EST Friday
 9:00am - 2:00pm EST Saturday

Thank You
For Choosing








Liability Statement
 SuperATV's[®] products are designed to best fit user's ATV/UTV under stock conditions. Adding, modifying, or fabricating any factory or aftermarket parts will void any warranty provided by SuperATV[®] and is not recommended. SuperATV's[®] products could interfere with other aftermarket accessories. If user has aftermarket products on machine, contact SuperATV[®] to verify that they will work together.

Although SuperATV[®] has thousands of satisfied customers, user should be aware that installing lift kits, long travel, or suspension kits, tires, etc. will change the ride of machine and may increase maintenance and part wear. Operating any off-road machine while, or after, consuming alcohol and/or drugs increases risk of bodily harm or death. No warranty or representation is made as to this product's ability to protect user from severe injury or death. SuperATV[®] urges operators and occupants to wear a helmet and appropriate riding gear at all times.


By purchasing and installing SuperATV[®] products, user agrees that should damages occur, SuperATV[®] will not be held responsible for loss of time, use, labor fees, replacement parts, or freight charges. SuperATV[®], nor any 3rd party, will not be held responsible for any direct, indirect, incidental, special, or consequential damages that result from any product purchased from SuperATV[®]. The total liability of seller to user for all damages, losses, and causes of action, if any, shall not exceed the total purchase price paid for the product that gave rise to the claim.

SuperATV[®] will warranty only parts provided by SuperATV[®]. Any damage or problems with OEM housings, bearings, seals, or other manufacturers' products will not be covered by SuperATV[®]. SuperATV[®] parts and products are not warranted if item was not installed properly, misused, or modified.


- Install Bracket, L to Cab Frame with hardware shown.
- Repeat for opposite side.



Ranger® XP 900: Install directly to Cab Frame with hardware shown.




- Install Tube, L to Bracket, L with hardware shown.



See following page for model specific configurations

Mid-Size Configuration




Full-Size Configuration

Set Screw →

Extension →

Wedge Clamps →

Tube, R →



Wedge Clamp Installation:

- Install into Tube or Extension.
- Tighten provided Set Screw.

Wedge Clamp halves

- Install Tube, R to Bracket, R with provided M8 hardware.
- Align assembly to machine and tighten all hardware completely.

