

# AIR BOX INTAKE TUBE

2020-2021 Polaris RZR ProXP

## PARTS LIST

---



- 1 INTAKE TUBE
- 2 CLAMPS

PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION



196030022.01



# INSTALLING THE INTAKE TUBE

- 1 Remove the two clamps securing the stock intake tube to the right rear fender inlet and to the air box.

**Note:** Removing the rear most seats and the firewall panel may aid in accessing the clamp on the air box.

- 2 Remove the stock intake tube.
- 3 Using the supplied clamps, install the Dynojet intake tube. Verify there is adequate clearance between the shock and the tube.





# **PUSH THE LIMIT**

**2191 MENDENHALL DRIVE, NORTH LAS VEGAS, NV 89081 - 800-992-4993 - DYNOJET.COM**

**© 2021 DYNOJET RESEARCH ALL RIGHTS RESERVED**