

## Installation Procedure

**Step 1: Remove the side skirts and plastic protective plate from the chassis.**



**Step 2: Remove the insert strip from the door side as the below pictures, and remove all the bolts (Please don't throw away these original bolts.)**





**Step3 : Put the running boards up and align the holes, all the holes are original.**



**Step4: Find the right position and tighten the bolts, all the bolts are used for the original bolts.**



**Step 5: Put back all the protective strips and the plastic protective plate on the chassis.**





**Step 6: Completion.**



**Disclaimer: Caused due to improper installation initiates some related problem and losses, are beyond our company' s quality assurance.**