

INSTALLATION INSTRUCTIONS - INS240

2009-2016 Dodge Ram 1500 5.7L VS // 2013-2016 Dodge Ram 2500 5.7L VS

COLD AIR INDUCTION







Difficulty: Very easy.





Note! The CARB EXEMPTION sticker included in the hardware kit must be PLACED UNDER-HOOD in a location visible by an emissions inspector during vehicle emission testing.



IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle.

BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019





FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

STEP 1

Disconnect the negative battery terminal.

STEP 2

Unplug the wiring harness that connects to the air temperature sensor on the stock inlet tube. Remove the sensor for re-use in the BBK inlet tube.

STEP 3

Disconnect the vacuum line from the stock air box and valve cover and remove completely. Use the supplied vacuum hose to replace it this hose will need to be cut to length.

STEP 4

Loosen the clamp on the inlet hose at the throttle body. Remove the inlet hose from the throttle body and lift up on the air box to remove it from its mounting points and remove it from the vehicle.

STEP 5

Install the BBK Cold Air Shield onto the stock mounting bracket pins. Line up the pins with the (2) rubber grommets on the air shield and press down firmly to secure the air shield in place.

STEP 6

Install the supplied rubber coupler and the (2) supplied clamps onto the throttle body.

STEP 7

Remove the air temp sensor from the stock inlet tube and Install the air temp sensor into the rubber grommet on the BBK Cold Air Tube that is closest to the end of the tube that connects to the throttle body.

STEP 8

Set the BBK Air Filter into the Air Shield and put the bottom of the air filter through the hole in the air shield then put one of the supplied clamps onto the end of the air filter.

STEP 9

Install the BBK Cold Air Tube into the inlet on the BBK air filter. Install the other end of the Cold Air Tube into the rubber coupler on the throttle body. Adjust the air tube for best fitment and tighten down all clamps to secure the air filter and air tube in place.

STEP 10

Install the barb vacuum fitting supplied in the kit into the rubber grommet on the air tube and connect the vacuum line to the barb fitting.

STEP 11

Reconnect the wiring harness plug onto the air temp sensor.

STEP 12

Re-connect the negative battery terminal. Start the vehicle and check for any air leaks.

YOUR INSTALL IS NOW COMPLETE

NOTE

The CARB EXEMPTION sticker included in the hardware kit must be PLACED UNDER-HOOD in a location visible by an emissions inspector during vehicle emission testing.



IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle.

BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019

