

R-1203

**2006 & UP, BMW E92 M3 COUPE HARNESS MOUNT BAR
INSTALLATION INSTRUCTIONS**

1. Remove rear lower seat cushion: Lift up on the front of the rear seat. (2 clips on each side.)
2. Remove side bolsters by pulling up on bolster toward the retractor and then tilting out.
3. Remove Seat hinge bolt. Place Brey Krause brackets over top of hinge. Replace bolt and tighten, both sides. Note: To open or close the back seat with the bar removed, place a piece of cardboard between the seat and bracket to prevent marking seat.



4. Floor Brackets. Remove plastic bolt cover. Remove bolt. Remove bar by turning over and sliding out. Bar has a 90 degree bend on the end. Remove the factory spacer in the floor. Slide the bar through the shoulder harness and then Brey Krause Floor Bracket. Reinstall bolt.



5. Outside Lap Belt. Remove bolt and mount under the bar. Replace bolt. Note: Brackets should lean towards the front of the car.



6. Install Bar. Insert the Aurora bushings with locknut into the down tubes. Place main bar in car with guide loops facing up. Insert the 7/16 bolt with lock washer (2 places). Do not tighten at this time. Attach the down tubes to the main bar with the 3/8-24 bolts. Attach the down tubes to the floor brackets with a 7/16 bolt with lock washer (2 places). Note: Adjust the length of the down tubes for height and level. Tighten all fasteners, including the jam nuts on the bushings.



Note: Periodically recheck fasteners for tightness. Shoulder straps should be wrap mounted around main tube and thru guides.

Performance driving events are by nature potentially hazardous to your health. Brey-Krause Mfg. Co. Inc. shall not be liable for injury, consequential, or other types of damages resulting from the use or misuse of our products. Proper installation of these parts is critical and should only be done by a professional shop.