

- 1. Long press the Power button to turn the Party Bar ON/OFF.
- 2. Click press the Power button to turn the LED Lights ON/OFF.
- 3. Dome button turns the LEDs ON and sets all LEDs to WHITE.
- 4. ACC button turns ON/OFF the accessory 12v pig tail for an external LED light bar or other accessory.
- 5. Press the Mode button to toggle between Bluetooth/Aux/USB listening modes.
- 6. Press > || to Pause/Play music.
- 7. Press Vol +/- to raise and lower the volume of the Party Bar.
- 8. Press |<< and >>| buttons to track forward/reverse on songs or to change the LED sequence when in LED mode.
- 9. Multi-pair up to 6 Dashboard Controllers to one G2 Party Bar.

Pair Dashboard Controller to Party Bar

- 1. Disconnect the power wire from the Party Bar, then press the ACC and the Pause/Play buttons at the same time to put the Dashboard Controller into matching mode.
- 2. The LCD display will show "CONNECT" indicating the remote controller is in matching mode.
- 3. Connect the Party Bar back to power within 45 secs, (ATTN! Plug the 12 V power wire into the speaker, do not just press the ON/OFF button) the display will show "MATCH OK" within 1 sec. This means your Dashboard Controller is successfully paired with the Party Bar.

Unleash the Sound and Illuminate Your Adventure

On Land or Over Water, Take the Party to the NEXT LEVEL in SOUND and LIGHTS!

