

POWERMADD®

Yamaha Extended Throttle Cable Kit

Installation Instructions for Part No. 43597

WARNING: Read all instructions before installing Extended Throttle Cable Kit. Snowmobile should not be running while installing or making any adjustments to the Extended Throttle Cable Kit. PowerMadd also recommends using a tether cord for the safest operation of your snowmobile. If at anytime you suspect there is a problem with the throttle controls, immediately shut off snowmobile and inspect. If you are experiencing problems with our Extended Throttle Cable Kit, contact PowerMadd for customer service 651-462-8465.

- Step 1:** Remove stock throttle cable and oil cable from the throttle lever the carbs. Take note of the cable routing in order to replicate when installing the new cables.
Note: Be sure to keep the c-clip for use on the new cables
- Step 2:** Attach the new cables to the throttle lever using the original c-clips.
- Step 3:** Route the cable down to the carbs in the same path as the original cables.
- Step 4:** Fasten the throttle cable to carbs and oil line to oil pump.
- Step 5:** Adjust the throttle and oil pump with the inline adjuster to factory specs.
- Step 6:** Double check install to ensure correct operation of both the throttle cable and oil line.

WARNING: Before starting the engine of this machine make certain that the throttle lever has the correct amount of free play by referring to the Owner's Manual. Check that the throttle is operating properly by opening and closing the throttle several times. Make certain the throttle returns to the idle position before starting. Raise the track completely off the ground using a secure track lift stand the first time the machine is started after installing the Throttle Cable Kit. Doing this will guard against the machine speeding off from improper throttle cable adjustment or the throttle not returning to idle.

LIMITED WARRANTY

POWERMADD warrants this product to be free from defects in material and workmanship under use for the purpose it was intended. POWERMADD shall not be liable for damage or injury caused by defective materials or workmanship. POWERMADD may elect to repair or replace this product, but is the sole judge of any defects in their product. This warranty does not cover any labor costs to remove or reinstall this product and is effect for one year from the original purchase date.