

**MQB EVO FWD Silicone Intake Hose****034 MOTORSPORT**

034Motorsport's upgraded air intake hose is designed to replace the restrictive corrugated factory unit and features a larger cross-sectional area with smooth internal walls for higher flow and increased performance. This durable, high quality silicone hose was modeled directly off the factory part to ensure perfect fit and finish, and extensively tested at 034Motorsport. In addition to cloth reinforcement, this hose features stainless steel wire reinforcement to prevent collapse under vacuum.

**Installation Spiciness Rating: MILD**

Installation of your 034Motorsport MK8 Silicone Intake Hose is a straightforward process that will take approximately 30 minutes to complete.

**Supplied Parts:**

- (1x) 034Motorsport intake hose w/ hose clamps

**Tools Needed:**

- Channel-lock pliers
- Flathead screwdriver

Getting Started

Confirm you have received all the parts included with your purchase by reading the complete guide, if there are missing components, please contact:

[customerservice@034motorsport.com](mailto:customerservice@034motorsport.com)


About This Guide

This Install Guide documents the installation process on a MK8 VW GTI. There may be minor differences depending on specific vehicle, market, options, etc.

### Install Steps


#### Step 1

Open your hood to access the intake.



#### Step 2

Using channel-lock pliers, loosen the hose clamp connecting the intake and airbox.



#### Step 3

Using a flathead screwdriver, loosen the hose clamp connecting the intake to the turbo inlet.



#### Step 4

Remove the factory intake hose.





#### Step 5

Install the 034 intake hose in the stock location.


#### Step 6

Using a flathead screwdriver, tighten the hose clamp connecting the intake to the airbox.



#### Step 7

Using a flathead screwdriver, tighten the hose clamp connecting the intake to the turbo inlet.



#### Step 8

You are done. Enjoy the added performance!

