

INTAKE UPGRADE KIT

2017-2020 Can-am X3 Turbo R models
Installation Guide

PARTS LIST



- | | |
|-----------------|----------------|
| 1 INTAKE TUBE | 1 HOSE COUPLER |
| 1 AIRBOX FLANGE | 3 CLAMPS |
| 1 BARB FITTING | |

**PLEASE READ ALL DIRECTIONS BEFORE STARTING INSTALLATION.
THE IGNITION MUST BE TURNED OFF BEFORE INSTALLATION.**




196030020.01



INSTALLING THE UPGRADE KIT


- 1 Slide the drivers seat forward or remove.
- 2 Remove the 2 bolts behind the seat holding the air box in place.
- 3 Remove the center engine access panel by pulling outwards. This panel is held in place by rubber grommets.



REMOVE AIR BOX BOLTS

- 4 Loosen the clamp on the small hose going into the intake tube, from the crankcase breather, and remove the hose.
- 5 Loosen the clamp on the intake boot to the turbo housing.

This image is shown with the Dynojet wastegate actuator in place



LOOSEN CLAMPS

- 6 Remove the clutch cover intake hose.
- 7 Loosen the clamp for the airbox intake hose
- 8 Remove the airbox assembly



REMOVE AIR BOX

INSTALLING THE UPGRADE KIT




CUT FLANGE

- 9 Cut the stock airbox flange using a hacksaw or similar tool so that flange outlet is flush.



REMOVE FLANGE

- 10 Cut a section out of the flange.
This will allow you to squeeze the opening and remove the flange from the airbox housing.



INSTALL FLANGE

- 11 Install the supplied barb fitting into the Dynojet flange.
- 12 Install the Dynojet flange into the stock airbox paying attention to the position of the barb fitting.

You will need to use a soft mallet to get the flange to seat into the airbox.

INSTALLING THE UPGRADE KIT

- 13 Install the hose coupler into the Dynojet tube using the supplied clamp.
- 14 Install the Dynojet tube onto the turbo using the supplied clamp.



INSTALL TUBE

- 15 Install the airbox using the supplied clamp.
- 16 Connect the crankcase breather hose to the Dynojet tube using the stock clamp.
- 17 Reinstall the access cover



INSTALL AIRBOX



PUSH THE LIMIT

2191 MENDENHALL DRIVE, NORTH LAS VEGAS, NV 89081 - 800-992-4993 - DYNOJET.COM

© 2016-2020 DYNOJET RESEARCH ALL RIGHTS RESERVED