

MQB Carbon Fiber Fresh Air Duct**034 MOTOR SPORT**

034Motorsport's Carbon Fiber Fresh Air Duct is now available for Volkswagen & Audi MQB and MQB EVO models with the 2.0T TFSI! Designed to better route cool, dense air from the front of the car to the airbox, this high-quality carbon fiber piece offers OEM+ fit and finish and is the perfect match for your X34 MQB Air Intake.

Installation Spiciness Rating: MILD

Installation of your Carbon Fiber Fresh Air Duct is a straightforward process that takes approximately one hour to complete.

Supplied Parts:

- 034Motorsport Carbon Fiber Fresh Air Intake Duct
- (2x) M4 Button-head Screws
- (2x) M4 Fender Washers
- (2x) Cable Clamps

Tools Needed:

- T25 Torx
- 2mm Allen
- Small Flathead Screwdriver

Getting Started

Confirm you have received all the parts included with your purchase by reading the complete guide, if there are missing components, please contact:

customerservice@034motorsport.com

About This Guide

This Install Guide documents the installation process on an 8V Audi S3. There may be minor differences depending on specific vehicle, market, options, etc.

Install Steps


Step 1

Allow the engine to sufficiently cool before tackling installation. Open the hood for access to the fresh air duct.



Step 2

Using a T25 Torx, remove the bolt securing the upper cover to the fresh air duct on both sides.



Step 3

Locate and lift the clip on the back side of the air duct.




Step 4

The cover should be free from the duct below. Now lift and pull forward to remove the cover completely from the duct.



Step 5


Your fresh air duct should look like the image below once the upper cover completely removed.

**Step 6**

Unclip the factory rubber hose from the 2 clips on the back side of the fresh air duct.

**Step 7**

Using a T25 Torx bit, remove the bolt securing each end of the fresh air duct to the radiator support. There will be 2 bolts total.

**Step 8**

With the bolts removed (see yellow arrow), push in the clip securing the rear duct to the main portion (see orange arrow).




Step 9

Lift the rear portion of the duct up and away from the ridge of the main fresh air duct.

**Step 10**

Remove the rear portion of the duct completely from the engine bay.

**Step 11**

Using a flathead screwdriver, push the clip in on either side of the air duct securing it to the radiator support, and slide the duct back.

**Step 12**

The factory duct should now be completely free and removed from the engine bay.



Step 13


With your new 034Motorsport carbon fiber fresh air duct, insert rear portion into airbox duct first.

**Step 14**


Once rear is inserted into airbox duct, slide forward snugly into core support.

**Step 15**

Ensure the holes line up from the 034Motorsport carbon fiber fresh air duct and the core support mounting holes.


**Step 16**

Use the supplied M4 bolt and washer to secure the carbon fiber fresh air duct on either side of the core support.



Step 17

Using a 2mm Allen key, gently snug each M4 screw on either side of the duct. **Note: Careful not to overtighten!**



Step 18

Reattach factory hose using supplied hose clamps and check that everything is snug. Remove tools from engine bay and enjoy the new look and sound of your car!

